









Setup



Charging




	
	Temp out of range, charging stopped
	Battery damaged
	Battery in regeneration
	Charging 0 % – 80 %
	Charging 81 % – 96 %
	Fully charged

* to be ordered separately

Digital 6000 System Instruction Manual

Sennheiser Documentation App



Available on the
App Store

or online at
www.sennheiser.com/download

SENNHEISER

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Publ. 04/17, 571337/A02